

# Post Panel Frame

## Assembly Instructions

### Components



x4 Bolts



x2 Frame Horizontals



x2 Frame Uprights



x1 Screw Driver  
(Not supplied)



x1 Panel  
(May be supplied or sourced separately)

**NOTE** The Frame Upright is directional, the lug nearest the end of the upright is the bottom.



**STEP 1**

Take one horizontal frame piece and one upright frame piece and align them in place.

**STEP 2**

Screw in the bolt to secure the horizontal frame piece to the upright frame piece.



**STEP 3**

Repeat this with the other upright frame piece so you have a "U" shape.



**STEP 4**

Stand the frame upright so that the horizontal frame is resting on the floor. Insert the panel into the slots on the frame uprights and slide it to the bottom of the frame.

**STEP 5**

Fit the remaining horizontal frame to the top of the panel and screw it into each end to complete the assembly.



**HINT**

Make sure all the bolts are tight otherwise the frame may flex.