



BELT CASSETTE REPLACEMENT

INSTRUCTIONS

2.5" Diameter and 3" Diameter Cassette



2.5" Diameter Cassette



3" Diameter Cassette



Phillips Screwdriver (not supplied)



1
Loosen the four screws securing the cassette into the post



2
Slide the cassette out of the post



3
Loosen the lower screws slightly on the replacement cassette but do not remove them completely. Do not loosen the top screws.



4
Fit the replacement cassette into the slots in the top of the post



5
Slide the cassette all the way down the post slots



6
Tighten the screws securing the cassette into the post
Note: Do not over tighten as this may affect the belt retraction.